QUICK START GUIDE

RF-PRO CONTROL SWITCH

Please read through all of the steps thoroughly before installation. It is essential to "Home Group" the Wall Switch to all of the alarms in the system, to ensure they will not communicate with any other nearby systems. Failure to "Home Group" the system will prevent it from operating correctly.

DO THIS BEFORE YOU INSTALL ANY OF THE DEVICES!

Turn the power on with the switch on the back of the Wall Switch.


Turn on all alarms to be installed in the system by sliding them onto their baseplates until they click into place.

"Home Group" all of the alarms in the system. To do this, press the small rectangular pairing button on the side of the alarm baseplate TWICE. A Red LED next to this button will flash 5 times. This alarm is now in the Home Group.

Repeat Step 4 for each additional alarm. Ensure the Red LED stays lit on the Wall Switch throughout – if it goes off before you have finished, repeat Step 3 and continue Step 4 with any alarms not yet joined to the Home Group.

Press and hold the "Home Group" button (H
CODE) on the back of the Wall Switch until the
Red LED lights up on the front as pictured below,
then release. Now the Wall Switch is in "Home
Grouping" mode.

Note: The "Home Grouping" mode on the controller will be active for 2 minutes 30 seconds. After this period, it will turn off automatically.



Now all of the devices are joined in the Home Group, they can be installed.

Note: The Wall Switch and all of the connected Home Group alarms have a memory function. When they are disconnected from their power supply or turned off (i.e. for installation), they will remain joined to the Home Group



For details on individual alarm devices, consult the instruction manuals enclosed with them.